

COAXIAL 12CO2P / 12CO2P-SLF*

Coaxial loudspeaker designed for professional use in touring or fixed applications. It employs a 1" titanium compression driver coupled with a 12" $\,$ woofer damped and cooled with ferrofluid (Ferrosound®). High perfomance compact systems can be designed easily with the added advantage of the almost point source characteristic that a coaxial offers, virtually eliminating the delay problem between adjacent acoustic sources. This coaxial loudspeaker can be successfully used in floor monitor applications or in sound reinforcement systems. Any suitable designed, bi-amplified system will deliver outstanding power with a superb frequency response.

*12CO2P-SLF: Product without Selenium logo printed on the dust cap.

SPECIFICATIONS

Nominal diameter	mm (in)
Nominal impedance8	Ω
Minimum impedance	
@ 236 Hz (woofer)	Ω
@ 2,580 Hz (driver)7.2	Ω
Power handling	
Musical Program (woofer) ¹	W
Musical Program (driver w/ xover 1,200 Hz / oct) ² 100	W
Sensitivity (2.83V @ 1m)	
averaged from 100 to 2,000 Hz (woofer)94	dB SPL
averaged from 1,200 to 5,000 Hz (driver)101	dB SPL
Frequency response @ -10 dB	
(woofer)	Hz
(driver)	Hz

THIELE-SMALL PARAMETERS (WOOFER)

Fs	Hz I (ft³) % m² (in²) cm³ (in³) mm (in) mm (in)
Re	I m Ω
Atmospheric conditions at TS parameter measurements: Temperature	°C (°F) mb %
Humidity	70

Thiele-Small parameters are measured after a 2-hour power test using half AES power . A variation of ± 15% is allowed.

NON-LINEAR PARAMETERS (WOOFER)


Le @ Fs (voice coil inductance @ Fs) 2.287	mΗ
Le @ 1 kHz (voice coil inductance @ 1 kHz) 0.863	mΗ
Le @ 20 kHz (voice coil inductance @ 20 kHz) 0.334	mΗ
Red @ Fs	Ω
Red @ 1 kHz2.26	Ω
Red @ 20 kHz30.03	Ω
Krm	$m\Omega$
Kxm13.833	mΗ
Erm	
Exm	

ADDITIONAL INFORMATION	
Magnet material (woofer and driver)	Barium ferrite
Magnet weight (woofer)	
Magnet weight (driver)920 (33)	g (oz)
Magnet diameter x depth (woofer) 169 x 19 (6.65 x 0.75)	mm (in)
Magnet diameter x depth (driver) 134 x 18 (5.28 x 0.71)	mm (in)
Magnetic assembly weight (woofer)4,200 (9.26)	g (lb)
Magnetic assembly weight (driver)	g (lb)
Frame material (woofer)	
Housing material (driver)	
Frame finish (woofer)	
Housing finish (driver)	
Voice coil material (woofer and driver)	
Voice coil former material (woofer and driver)Polyi	
Cone material (woofer)	
Diaphragm material (driver)	
Volume displaced by coaxial	
Net weight	
Gross weight	g (lb)
Carton dimensions (W x D x H) 34 x 34 x 23 (13.39 x 13.39 x 9.06)	cm (in)

MOUNTING INFORMATION

Number of boil-notes		
Bolt-hole diameter	5.5 (0.22)	mm (in)
Bolt-circle diameter	292 (11.50)	mm (in)
Baffle cutout diameter (front mount)	280 (11.02)	mm (in)
Baffle cutout diameter (rear mount)	275 (10.83)	mm (in)
Connectors	Silver-plated	push teminals
Polarity	Positive voltage applied	to the positive
	(+) terminal gives forward	d cone motion
Minimum clearance between the back		

of the magnetic assembly and the enclosure wall75 (3) mm (in)




¹ Power handling specifications refer to normal speech and/or music program material, reproduced by an amplifier producing no more than 5% distortion. Power is calculated as true RMS voltage squared divided by the nominal impedance of the loudspeaker. ² Power handling specifications refer to normal speech and/or music program material, reproduced by an amplifier producing no more than 5% distortion. Power is calculated as true RMS voltage squared divided by the nominal impedance of the loudspeaker. This voltage is measured at the input of the recommended passive crossover when placed between the power amplifier and loudspeaker. Musical Program= 2 x W RMS.




COAXIAL 12CO2P / 12CO2P-SLF*


WOOFER AND DRIVER RESPONSE CURVES IN A TEST ENCLOSURE INSIDE AN ANECHOIC CHAMBER, 1 W / 1 m



DRIVER HARMONIC DISTORTION CURVES, 5 W / 1 m.




WOOFER AND DRIVER IMPEDANCE AND PHASE CURVES




Driver Impedance Curve.Driver Phase Curve.

WOOFER HARMONIC DISTORTION CURVES MEASURED AT 10% AES INPUT POWER, 1 m $\,$



POLAR RESPONSE CURVES



HOW TO CHOOSE THE RIGHT AMPLIFIER

The power amplifier must be able to supply twice the RMS driver power. This 3 dB headroom is necessary to handle the peaks that are common to musical programs. When the amplifier clips those peaks, high distortion arises and this may damage the transducer due to excessive heat. The use of compressors is a good practice to reduce music dynamics to safe levels.

NON-LINEAR VOICE COIL PARAMETERS

Due to its close coupling with the magnetic assembly, the voice coil in electrodynamic loudspeakers is a very non-linear circuit. Using the non-linear modeling parameters Krm, Kxm, Erm, Exm from an empirical model, we can calculate voice coil impedance with good accuracy.

SUGGESTED PROJECTS

For additional project suggestions, please access our website.

TEST ENCLOSURE

65-liter volume with a duct ø 4" by 0.8" length. Kapton®: Du Pont trademark. Ferrosound®: Ferrofluidics Corporation trademark.

Specifications subject to change without prior notice.

Cod.: 150865 Rev.: 01- 10/04

ELETRÔNICA SELENIUM S.A.
BR 386 Km 435 - Nova Santa Rita/RS - Brasil CEP 92480-000
Tel.: 51. 479 4000 Fax: 51. 479 1150
www.selenium.com.br
Atendimento Técnico: 0800 514161

FILIAL SÃO PAULO Rua Aquinos, 157 - São Paulo/SP - Brasil - CEP 05036-070 Tel.: 11.3611 3977 Fax: 11.3611 2941

> SELENIUM USA / SELENIUM EUROPE www.seleniumloudspeakers.com Tool Free: 1800 5620510